

Schlüsselnummern Ford Fiesta: Mk1-Mk7

Fiesta Mk1 GFBT/WFBT

|          |          |          |     |
|----------|----------|----------|-----|
| 0,9 45PS | 0928-476 | 7528-302 | TLA |
| 1,1      | 0928-477 | 7528-303 | GLA |
| 1,3      | 0928-494 | 7528-304 | J3E |
| 1,6 84PS |          | 7528-306 | L3E |

Fiesta Mk2 FBD

|          |          |          |     |
|----------|----------|----------|-----|
| 1,0      | 0928-581 | 7528-311 | TKB |
| 1,1 50PS | 0928-582 | 7528-312 | GLC |
| 1,3      | 0928-592 | 7528-317 | JPC |
| 1,4 75PS | 0928-614 | 7528-321 | FUB |
| 1,6 95PS | 0928-642 | 7528-333 | LUD |
| 1,6 97PS |          | 7528-319 | LUB |
| 1,6D     | 0928-593 | 7528-318 | LTB |

Fiesta Mk3 GFJ

|           |          |          |          |          |          |     |
|-----------|----------|----------|----------|----------|----------|-----|
| 1,1 i     | 0928-712 | 0928-785 | 2028-321 | 7528-345 | 7528-368 | G6A |
| 1,3 i     | 0928-788 |          | 2028-325 | 7528-369 |          | J6B |
| 1,4 i     | 0928-713 |          | 2028-361 | 7528-346 |          | F4A |
| 1,6 8V    | 0928-715 |          | 2028-323 | 7528-346 |          | LJD |
| 1,6 16V   | 0928-864 |          | 2028-362 | 7528-361 |          | L1G |
| 1,8 105PS | 0928-806 |          | 2028-326 | 7528-371 |          | RDB |
| 1,8 130PS | 0928-807 |          | 2028-327 | 7528-372 |          | RQC |
| 1,8 D     | 0928-714 |          | 2028-322 | 7528-347 |          | RTD |

Fiesta Mk4/Mk5 JAS/JBS

|          |          |          |     |
|----------|----------|----------|-----|
| 1,25     | 0928-930 | 0928-934 | DHA |
| 1,3 50PS | 0928-928 | 0928-932 | JJA |
| 1,3 60PS | 0928-929 | 0928-933 | J4C |
| 1,4 16V  | 0928-954 | 0928-956 | FHA |
| 1,6 16V  | 8566-396 | 8566-455 | L1T |

Fiesta Mk6 JH1/JD3

|           |          |          |          |          |          |      |
|-----------|----------|----------|----------|----------|----------|------|
| 1,25 75PS | 8566-514 | 8566-518 | 8566-ACL | 8566-ACT |          | FUJA |
| 1,3 60PS  | 8566-499 | 8566-505 | 8566-515 | 8566-ACJ | 8566-ACR | BAJA |
| 1,3 70PS  | 8566-498 | 8566-506 | 8566-517 | 8566-ACI | 8566-ACQ | A9JA |
| 1,4 16V   | 8566-490 | 8566-519 | 8566-ACM | 8566-ACU |          | FXJA |
| 1,6 16V   | 8566-491 | 8566-520 | 8566-ACN | 8566-ACV |          | FYJA |
| 2,0       | 8566-591 | 8566-ACP |          |          |          | N4JB |
| 1,4 D     | 8566-489 | 8566-516 | 8566-ACK | 8566-ACS |          | F6JA |
| 1,6 D     | 8566-590 | 8566-592 | 8566-ACO | 8566-ACW |          | HHJA |

Fiesta Mk7 JA8

|            |          |
|------------|----------|
| 1,25 60PS  | 8566-AOO |
| 1,25 82PS  | 8566-AOP |
| 1,4        | 8566-AOQ |
| 1,6        | 8566-AOR |
| 1,4 D      | 8566-AOS |
| 1,6 D 75PS | 8566-AQD |
| 1,6 D 90PS | 8566-AOT |